# FIELD GUIDE TO RESISTORS

In order for an electrical circuit to function properly, the power requirements, size and complexity of the circuit need to be in perfect balance. Too much power and the circuit will fail; too little and it may not function at all. You can achieve this balance by using a type of component called a resistor to introduce resistance in the circuit and ensure your components function properly.



## HOW TO READ COLOR BANDS

### **RESISTOR TYPES**

Different types, sizes and complexities of electrical circuits use a mind-boggling variety of resistors. Here are a few of the most common types you may encounter.



#### **CARBON FILM**

Carbon film resistors are the archetypical resistor encountered in DIY electronics. Inexpensive and available in thousands of values, they've been used in electrical circuits for over 100 years.

#### **COMMONLY FOUND**

These can be found almost everywhere. These are the breadboard-friendly resistors that end up in all kits, and in most soldering projects.

### POWER RESISTOR

Power resistors are the best choice when you're dealing with higher power levels.

					5 - B A N D 6 - B A N D					2	236Ω 87MΩ ±5%	±1% 100P	PM
					C			9					
					SILVER	0.01			SILVER	±10%			
					GOLD	0.1			GOLD	±5%			
	BLACK	0			BLACK	р л. 1 л.							
E VALUES	BROWN	1			BROWN	10			BROWN	±1%	L	<sup>∪</sup> ⊢	BR
	R E D	2			R E D	100	TOLERAN	AN	RED	±2%		5Z	R E
	ORANGE	3		MULTIPL	ORANGE	1 K		Ш Ш			F		OR
	YELLOW	4			YELLOW	10K		0 0					ΥE
	GREEN	5			GREEN	100K			GREEN	±0.5%	Σ	LШ	
A C	BLUE	6			BLUE	1 M			BLUE	±0.25%	L F	ĽŬ	4
	VIOLET	7			VIOLET	10M			VIOLET	±0.10%			A
	GRAY	8			GRAY	100M			GRAY	±0.05%			СС
	WHITE	9			WHITE	1G			ter i 141 - 16 an an an thair a cai				it: to
	2014 CONTRACTOR SPECIAL	HAR THE AND THE A											to

#### **1: BASE VALUE**

The first two or three color bands indicate the first, second and third resistor values and their place values respectively. For example, a brown band, (1), followed by a red band, (2), would indicate a base value of  $12\Omega$ 

### 2: MULTIPLIER

For resistors that have values with three or more place values, a multiplier band is used - K (kilo) indicating 1,000, M (mega) indicating one million and G (giga) indicating 1,000 million. Resistors not needing a multiplier will still display a black multiplier band.

4-BAND

#### **3: RESISTOR** TOLERANCE

Even though resistors are manufactured to precise specifications, they aren't perfect. The tolerance value indicates what percentage of voltage, higher, or lower, that the resistor will allow through the circuit.

ᄥ⊢	BROWN	100PPM
	RED	5 0 P P M
CLA	ORANGE	1 5 P P M
P F F	YELLOW	2 5 P P M
Ш Ш Ш Ш Ш Ш	4. MAN	AGING

10KΩ ±5%

#### . IVIAIVAUINU **EMPERATURE**

resistor's temperature oefficient describes how much s tolerance can change relative o changes in temperature. The temperature coefficient of resistance, or TCR, is measured in parts per million °C. A resistor with a TCR value of 100ppm will not change in tolerance more than 0.00010% per ohm, per degree celcius.

They come in significantly larger power ratings than standard resistors (into full watts), and are typically large enough to have their value printed on their housing instead of using color bars.

#### COMMONLY FOUND

Commonly seen in heating applications, due to the heat they generate. Some applications may even have cooling elements or a liquid cooling system.

#### **METAL FILM**

\_\_\_\_\_

Metal film resistors, like carbon film resistors, are among the most common resistors you'll find in electrical circuits. They are the logical outgrowth of the wire-wound resistors that populated the golden age of radio electronics.

#### **COMMONLY FOUND**

These are very precise resistors. Their stability and accuracy make them a great choice for critical projects that demand a high level of accuracy.

#### **THROUGH-HOLE**

Through-hole components have been at the center of small projects for a long time. Both carbon film and metal film resistors are typically found in through-hole applications and need to be used on circuit boards that are drilled for PTH components.

#### **COMMONLY FOUND**

PTH or "plated through-hole" resistors are an easy choice for common breadboarding activities and simple prototypes that don't require mass production.

## COLOR BAND EXAMPLES





through-hole counterparts.

typically much smaller than their

**COMMONLY FOUND** They are at the heart of large-scale, commercial circuit board production and manufacturing for many applications.

# Learn More

**KEEP GOING!** If you want to learn more about resistors, circuits and how to use them appropriately in your next project, you can find plenty of tutorials and guides at learn.sparkfun.com.

